

Base Drawer Cabinets
BASE CABINETS

SKU	OAK		MAPLE										JEFFERSON & WINDSOR		GRANTLEY		
	HAVEN	OXFORD	HAVEN		OXFORD		MILTON		DOVER			stain	stain w/glaze	paint or paint w/glaze	stain	stain w/glaze	paint or paint w/glaze
BASE – TWO TOP DRAWERS																	
B30D2	556	583	571	666	598	699	630	739	737	803	873	649	704	763	712	775	842
B33D2	575	598	592	692	621	728	683	806	766	835	909	668	725	787	737	803	873
B36D2	587	617	605	708	637	748	696	822	787	859	936	688	748	812	755	823	896
B39D2	618	644	642	754	672	792	716	847	831	908	991	716	779	847	788	860	937
B42D2	625	656	649	763	682	804	725	858	848	927	1012	728	793	862	798	871	949
B48D2	656	690	678	799	715	846	758	899	891	975	1066	772	842	917	843	921	1006
BASE – TWO TOP DRAWERS, ONE ROLL-OUT																	
B30R01D2	677	707	692	797	723	836	760	882	873	945	1023	779	840	906	846	915	990
B33R01D2	701	726	718	830	750	870	817	953	906	982	1065	803	867	936	875	948	1026
B36R01D2	713	745	731	846	767	891	831	971	929	1008	1093	824	891	962	894	969	1050
B39R01D2	744	774	769	893	804	937	851	996	974	1059	1150	852	922	997	927	1006	1091
B42R01D2	752	787	777	903	813	948	860	1007	991	1078	1171	865	937	1013	938	1018	1105
BASE – TWO TOP DRAWERS, TWO ROLL-OUTS																	
B30R02D2	806	839	821	939	854	980	895	1031	1015	1095	1181	915	983	1056	985	1061	1144
B33R02D2	832	861	849	974	885	1019	956	1107	1052	1136	1227	943	1014	1091	1017	1097	1184
B36R02D2	847	883	866	995	905	1044	974	1130	1078	1166	1260	967	1041	1121	1040	1123	1212
B39R02D2	882	916	907	1046	946	1095	999	1161	1128	1222	1322	1000	1078	1162	1078	1166	1260
B42R02D2	892	930	916	1057	957	1109	1010	1175	1147	1243	1346	1014	1094	1180	1091	1180	1276
BASE – THREE DRAWERS																	
DB12	512	532	516	586	537	612	551	630	628	675	726	575	616	660	627	674	725
DB15	529	551	536	611	558	639	578	664	657	708	762	598	642	689	650	700	754
DB18	546	567	552	631	575	660	611	705	681	735	792	619	665	715	672	725	781
DB21	564	587	572	656	596	686	625	722	710	767	829	640	689	741	696	752	811
DB24	580	604	590	679	614	709	642	744	736	796	861	663	715	770	722	781	844
BASE – FOUR DRAWERS																	
DB12D4	631	655	637	718	660	746	672	761	772	827	886	707	754	805	766	820	879
DB15D4	642	667	651	735	673	763	691	785	793	851	913	723	772	825	780	836	896
DB18D4	659	686	667	755	693	788	727	830	818	879	944	745	797	853	806	865	929
DB21D4	680	708	693	788	715	815	744	851	855	920	990	770	825	884	833	896	963
DB24D4	700	729	711	810	738	844	764	876	883	952	1025	797	855	918	859	925	995
BASE – POT AND PAN, TWO DRAWERS																	
DBPP15D2	552	576	559	660	590	698	629	747	707	773	845	632	689	751	685	749	817
DBPP18D2	568	595	575	680	606	718	651	775	728	797	871	652	712	776	704	770	841
DBPP21D2	585	613	597	707	628	746	680	811	754	826	903	683	746	815	737	807	882
DBPP24D2	606	636	617	732	651	775	698	833	786	862	943	701	767	837	757	829	907
BASE – POT AND PAN, THREE DRAWERS																	
DBPP30	755	791	774	909	809	952	884	1046	978	1067	1164	866	942	1024	937	1021	1112
DBPP33	775	808	792	931	830	979	903	1070	1005	1098	1197	892	971	1056	963	1051	1145
DBPP36	803	841	823	970	863	1020	934	1109	1048	1146	1251	940	1025	1116	1007	1100	1200
BASE RANGE TOP, TWO DRAWERS																	
BRT30D2	668	704	690	823	724	866	801	962	897	986	1082	782	857	938	856	940	1031
BRT33D2	686	719	704	841	742	888	817	982	921	1013	1112	803	881	965	879	966	1060
BRT36D2	714	751	735	880	775	930	847	1020	964	1061	1166	853	937	1027	922	1014	1113