



# Wall Cabinets / Square Corner | 12" Deep


Design Tips:		SMARTSHIELD				BIRCH						
		ELLSTON	ELLIOT	CARVER	LIVINGSTON EMERY	DARROW		FREMONT		WINSLOW		
• When cabinet is "pulled", it will use proportionally more wall space. For example, a 30" wide Wall cabinet pulled 2" will use 32" of space	• Blind side of Wall Corner cabinets cannot be installed next to a Range Hood or Microwave Shelf door due to door interference	SKU	cubes	SS	SS	SS	SS	Stain	Paint	Stain	Glaze	Stain
• Cabinets can be flipped during installation for right hinge applications	• Reference Installation Charts for proper sizing identification, see page 70											


## SQUARE CORNER WALL - 30" HIGH - 12" DEEP

 <ul style="list-style-type: none"> <li>• One door</li> <li>• Two adjustable shelves</li> <li>• Door attaches to the blind panel; Hinging determines the location of the blind</li> <li>• Cover panel shipped with cabinet for field installation to cover 6" blind opening</li> <li>• Includes 3" filler</li> <li>• Available widths: 24"-36"</li> </ul>  	SC2430	6.2	367	377	465	526	377	422	405	465	422
	SC3030	7.6	407	417	521	603	417	472	453	521	472
	SC3330	8.4	425	437	545	620	437	493	471	545	493
	SC3630	9.1	441	454	568	639	454	511	493	568	511

 <ul style="list-style-type: none"> <li>• Two butt doors</li> <li>• Two adjustable shelves</li> <li>• Door attaches to the blind panel; Hinging determines the location of the blind</li> <li>• Cover panel shipped with cabinet for field installation to cover 6" blind opening</li> <li>• Includes 3" filler</li> <li>• Available widths: 42" and 48"</li> </ul>  	SC4230B	10.6	498	514	645	738	514	585	559	645	585
	SC4830B	12.1	555	571	718	816	571	645	618	718	645

## SQUARE CORNER WALL - 36" HIGH - 12" DEEP

 <ul style="list-style-type: none"> <li>• One door</li> <li>• Two adjustable shelves</li> <li>• Door attaches to the blind panel; Hinging determines the location of the blind</li> <li>• Cover panel shipped with cabinet for field installation to cover 6" blind opening</li> <li>• Includes 3" filler</li> <li>• Available widths: 24"-36"</li> </ul>  	SC2436	7.3	421	433	537	627	433	486	467	537	486
	SC3036	9.1	479	494	614	726	494	555	532	614	555
	SC3336	10.0	494	509	639	748	509	575	551	639	575
	SC3636	10.9	511	526	660	766	526	598	571	660	598

 <ul style="list-style-type: none"> <li>• Two butt doors</li> <li>• Two adjustable shelves</li> <li>• Door attaches to the blind panel; Hinging determines the location of the blind</li> <li>• Cover panel shipped with cabinet for field installation to cover 6" blind opening</li> <li>• Includes 3" filler</li> <li>• Available widths: 42" and 48"</li> </ul>  	SC4236B	12.5	543	559	707	807	559	636	607	707	636
	SC4836B	14.3	580	597	752	859	597	678	648	752	678